



Zero Factory Harness ID Schdule

Connector	Contact	Harness wire colour	Circuit	Connection Pt No.	Connection Colour	Pin
Ignition switch	1	red	12v fuse supply	ford switch	Red	30 R 15 50
	2	yellow	axillary isolator relay switch		yellow	
	3	blacks	12v ignition out		black/yellow	
	4	pink	start solenoid out		black/blue	
	A (single)	pink	start solenoid 12v (option)		aux start button	
Left headlight	1	white	left front head main	LTSLA01	Blue/White	
	2	yellow	left front head dip		Blue/Red	
	3	green	left front side		Red/White	
	4	brown	left front ground		Black	
Left front turn Nose	1	blue	left front turn signal	LTIN04	Black/White	
	2	brown	left front turn ground		Black	
Left Front Wing Repeater	1	blue	left front turn signal	LTIN07	Black	
	2	brown	left front turn ground		Yellow	
Right headlight	1	white	right front head main	LTSLA01	Blue/White	
	2	yellow	right front head dip		Blue/Red	
	3	green	right front side		Red/White	
	4	brown	right front ground		Black	
Right front turn	1	violet	right front turn signal	LTIN04	Black/White	
	2	brown	right front turn ground		Black	
Right front wing repeater	1	violet	right front turn signal	LTIN07	Black	
	2	brown	right front turn ground		Yellow	
Radiator fan	1	red	cooling fan supply	CSFN03	+	
	2	brown	cooling fan ground		-	
Horn	1	orange	horn supply	ELHN01	+	
	2	brown	horn ground		-	
Left tail light cluster	1	green	left rear tail	LTRC01	red	
	2	red	left rear stop		green/violet	
	3	blue	left rear turn		green	
	4	brown	left rear ground		black	
Right tail light cluster	1	green	right rear tail	LTRC01	red	
	2	red	right rear stop		green/violet	
	3	violet	right rear turn		green	
	4	brown	right rear ground		black	
Stop light switch	1	black	ignition + in	BRA10	terminal	
	2	red	right rear stop (out)		terminal	
Fuel level sender	1	yellow	fuel level signal	TA9110-000- (smiths)	terminal	
	2	brown	fuel level ground		fixing screw	
Fuel pump	1	grey	fuel pump supply	FS26	red	
	2	brown	fuel pump ground		black	
Rear fog light	1	red	rear fog	LTRF02	terminal	
	2	brown	rear fog ground		terminal	
Number plate light	1	green	no plate	LTNP01	terminal	
	2	brown	no plate ground		terminal	
Reverse light	1	white	reverse light	LTRV03	terminal	
	2	brown	reverse light ground		terminal	
Reversing light switch	1	black	+ in		terminal	
	2	white	+ out		terminal	
Handbrake warning light switch	1	red	handbrake warning lamp		terminal	
	2	brown	handbrake switch ground		terminal	
Starter motor	1	pink	+start	ELSM01	terminal	
Washer pump	1	white	washer pump +		terminal	
	2	brown	Washer pump ground -		terminal	
axillary switches V1,1	1	red/green	side light			
	2	red (1mm)	rear fog			
	3	brown	axillary switch ground			
	4	red (0.5mm)	axillary hazard switch +			
	5	yellow	flash relay signal			
	6	blue	left turn			
	7	violet	right turn			
	8	red (0.5mm)	axillary hazard switch 12v out			
	A (single)	grey	spare 12v feed			
	B (single)	yellow	dip beam signal			
axillary switches V1,2	1	green	side light			
	2	red (1mm)	rear fog			
	3	brown	axillary switch ground			
	4	red (0.5mm)	axillary hazard switch +			
	5	yellow	flash relay signal			
	6	blue	left turn			
	7	violet	right turn			
	8	red (0.5mm)	axillary hazard switch 12v out			
	9	grey	spare 12v feed			
	10	yellow	dip beam signal			
	11	orange	horn switch (to ground)			